HAZUS-MH and Dam Inundation



Objectives

Introduction to HAZUS-MH

Flood Information Tool (FIT)

HAZUS Output

HAZUS-MH Support Network

HAZUS Training

History

Program initiated in 1992

Earthquake model versions developed in 1997, 1999, 2000, 2001, 2002, 2005, 2006, and 2007

Development of Hurricane and Flood models initiated in 1998

Multi-hazard HAZUS (HAZUS-MH) with models for hurricane, flood and earthquake hazards released in Spring 2004

HAZUS-MH Maintenance Releases in Jan. 2005, June 2006, and June 2007

What is HAZUS-MH?

GIS-based tool used on a personal computer

Available from FEMA free of charge (http://www.fema.gov/plan/prevent/hazus/)

Requires installation of ArcGIS 9.2, ArcGIS Spatial Analyst 9.x (for flood modeling), and applicable ArcGIS service packs



Supported Hazards



Hurricane Winds




Riverine and Coastal Floods



Earthquakes


How does HAZUS-MH estimate losses?



Inventory (Exposure) Data

HAZUS-MH provided data:

- Common to all hazards
 - General building types and occupancies
 - Lifelines
 - Replacement costs
 - Demographics
- Hazard-specific
 - Specific building types
 - Elevation
 - Building configurations



Tools for Integrating Local Data

Data Integration Tools

- Building Import Tool (BIT)
- Flood Information Tool (FIT)
- Comprehensive Data Management System (CDMS)

Linkage to third-party Models

- Areal Locations of Hazardous Atmospheres (ALOHA)
- Flood Waves (FLDWAV)

NOTE: These tools are covered in advanced courses


Flood Information Tool (FIT)

What is the Flood Information Tool (FIT)?

System of tools that generate a floodplain based on user provided input

Input sources

- Flood engineering reports
- User-run models



Key FIT Functionality

Validation of input spatial data

Development of flood elevation and depth grids

Analysis of non-conveyance areas


Interpolation of grids for return periods not included in input data

Required Input Data

Terrain (Digital Elevation Model)

ArcInfo grid processed to bare-earth conditions

Tutorials aid in conversion of various topographic data (spot elevations, contours, TINs) to the grid format



Required Input Data


Flood Elevation Cross Sections

Line feature class

Cannot intersect each other, but should intersect floodplains

Must be attributed with flood surface elevation for desired return period

Discharge values are not used except for interpolating additional flood depth grids



606.11 608.05 3792 7006 8053 9887 11246 606.48 608.3 3792 7006 8053 9887 11246 607.71 609.7 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 610.87 613.4 3792 7006 8053 9887 11246	EL_100_YR	EL_500_YR	Q_2_YR	Q_10_YR	Q_25_YR	Q_50_YR	Q_100_YR
607.71 609.7 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246	606.11	608.05	3792	7006	8053	9887	11246
608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246	606.48	608.3	3792	7006	8053	9887	11246
609.71 612.21 3792 7006 8053 9887 11246 608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246 11246	607.71	609.7	3792	7006	8053	9887	11246
608.58 610.76 3792 7006 8053 9887 11246 609.71 612.21 3792 7006 8053 9887 11246	608.58	610.76	3792	7006	8053	9887	11246
609.71 612.21 3792 7006 8053 9887 11246	609.71	612.21	3792	7006	8053	9887	11246
AND THE PROPERTY OF THE PROPER	608.58	610.76	3792	7006	8053	9887	11246
610.87 613.4 3792 7006 8053 9887 11246	609.71	612.21	3792	7006	8053	9887	11246
	610,87	613.4	3792	7006	8053	9887	11246

Required Input Data

Floodplain Analysis Boundary

Polygon feature class

Must be single contiguous polygon


Helps define the limits of analysis

Potential sources: DFIRM, Q3




Project Setup & Validation

User is prompted to identify input data



Project Setup & Validation

Validation Error Alerts



Yertical Units

The vertical units for the flood elevation map layer have not been selected. Please use the elevation units combo box to select the vertical units for the flood elevation map layer.

OK

Checks user input for required fields

Verifies consistency


Successful validation allows enabling of analysis menu items

Flooding Mechanisms

Conveyance – water flows upstream to downstream, flood elevations decay between adjacent cross sections


Backwater – water backs up from the main channel to a tributary

or low-lying area




Centerline

"Ball" expands and contracts along flood plain boundary in conveyance areas




Centerline

Centerline represents the center of the floodplain, not the center of the stream.



Cross Sections


In FIT, you can define your own upstream and downstream limits to tailor your study area.



Cross Section Extension


A series of buffers is created between the centerline and the bounding polygon.

Cross sections are extended to bounding polygon if necessary.




Flood Elevation Points

Flood elevation points at regular intervals are interpolated between cross sections.




Flood Elevation Grid

Flood surface is interpolated from elevation points.




Flood Depth Grid


Flood depth grid = flood surface - ground elevation.




Stream Limits Dialog is used to identify the upstream and downstream limits of the study area.



Centerline buffer captures area of conveyance.



Associate flood elevation and discharge fields with return period.




Depth Grid Wizard Output

Depth Grid

Flood boundary

Backlines (if needed)




Possible Threshold 'Errors'

Option 1: Increase the Center line buffer.

Option 2: Increase Depth Threshold.

Option 3: Leave as is and continue.





Identifies non-conveyance areas (ponds) of flooding

Establishes flood elevations for non-conveyance areas


Adjusts the flood elevation and depth grids to include backwater areas








Results




Import to HAZUS-MH


- Click on the Hazard\User Data menu item and click the FIT tab.
- 2. Browse for the location of the FIT project(s) that you want to use.



Import to HAZUS-MH

- 3. In New Scenario, use the FIT analysis areas radio button.
- 4. Compute hydraulics.





Additional User Provided Hazard Options




Quick Look Feature

Allows user to estimate damage without running hydrology and hydraulics analysis.

User creates flood boundary and enters flood depth.

Estimates general building stock damage assuming uniform flood depth within polygon.

No DEM input is required.



Note: This feature can only be used in a study region in which no scenarios are open.

Quick Look Analysis

The Quick Look and the Enhanced Quick Look analysis are both run by selecting Quick Analysis.


Only general building stock is analyzed, so no options exist for which analysis components to run.



Quick Look Results

Both the Quick
Look and
Enhanced Quick
Look tools generate
a single report.

Only general building stock damage is reported.




Enhanced Quick Look

User supplies both a DEM and a flood boundary.

HAZUS-MH creates a depth grid within the boundary and estimates general building stock building damage.

Note: This feature can only be used in a study region in which no scenarios are open.




User Defined Flood Depth Grid

HAZUS-MH allows users to point to one or more existing flood depth grids.

- Must use ArcInfo GRID format
- Depth units are defined by user
- Can use any projected coordinate system


This option represents the most accurate representation of a flood hazard assuming that the depth grid has been created with appropriate methods.



User Defined Flood Depth Grid

Assign the depth grid, along with relevant FIT areas or reaches, to a scenario.

All analysis output options available.




HEC-RAS Depth Grids

HEC-RAS (Hydrologic Engineering Center's River Analysis System) is a software package from the US Army Corps of Engineers that enables users to perform one-dimensional

hydraulic calculations.

HAZUS-MH can use HEC-RAS output for enhanced dam or levee analysis.






HEC-RAS Depth Grids

HAZUS-MH integrate HEC-RAS output in version 4.1 or later of HEC-RAS.


The floating-point binary (.flt) file is the file that you need to import into HAZUS-MH.



HEC-RAS Depth Grids


Output will show flood boundaries.


Important: HAZUS-MH only computes still water damages. Damages related to velocity from a dam or levee break is not calculated.





HAZUS-MH Output






HAZUS-MH Output

	Earthquake Ground Shaking Ground Failure	Flood Frequency Depth Discharge Velocity	Hurricane Wind Pressure Missile Rain				
Direct Damage							
General Building Stock	\checkmark	√	\checkmark				
Essential Facilities	√	✓	✓				
High Potential Loss Facilities	√						
Transportation Systems	√	✓					
Utility Systems	✓	✓					
Induced Damage							
Fire Following	✓						
Hazardous Materials Release	√						
Debris Generation	\checkmark	\checkmark	\checkmark				
→Direct Losses							
Cost of Repair	√	√ ₁	\checkmark				
Income Loss	\checkmark	\checkmark	\checkmark				
Crop Damage		\checkmark					
Casualties	\checkmark	Generic Output					
Shelter Needs	\checkmark	\checkmark	✓				
Indirect Losses							
Supply Shortages	√	√					
Sales Decline	\checkmark	\checkmark					
Opportunity Costs	√	\checkmark					
Economic Loss	\checkmark	\checkmark					

HAZUS-MH in Emergency Management




FEMA Resources

HAZUS-MH Overview

Software Order Forms

Training / Conference Information

FAQs



http://www.fema.gov/plan/prevent/hazus/

User Groups

Latest news

User feedback

User group contacts



Supporting the HAZUS user community across the country, the ultimate on-line resource for everything HAZUS ...



About	FEMA HAZUS	HAZUS.org	Contact	HAZUS.org
HAZUS.org	Web Pages	Resources	HAZUS.org	Affiliates

- ▶ Join HAZUS.org
- ► HAZUS User Groups
- ► HAZUS Training & Technical Assistance
- ► HAZUS.org Special Interest Groups
- HAZUS Success Stories



The National HAZUS User Conference will be held concurrent with the 2007 ESRI International User Conference.

For more info and to see how you can participate, <u>b</u> <u>click here...</u>

FEMA HAZUS User of the Month...

As a way of recognizing those individuals who are dedicated to furthering the success of HAZUS?, FEMA has created the HAZUS User of the Month designation to help show appreciation to those who have contributed to the success of the program. For more info and to download the pomination form

Breaking News...

- Institute on Disabilities and the Center of Preparedness, Education and Practice at Temple University announce the establishment of a listserv and web site for Special Populations Analysis and Research with GIS (SPAR-GIS). For more info, Eclick here...
- ► Western Disaster Center and Jamie Caplan Consulting team to develop and promote HAZUS.org. For more info. ►click here...
- ► Are We Ready? The Public Readiness Index: A Survey-Based Tool to Measure the Preparedness of Individuals, Families and Communities. To download the report, <u>▶click here</u>. To read more about this research, ▶click here.

Upcoming Events...

- ► Congressional Hazards Caucus Alliance briefing and panel discussion - End-To-End Disaster Communications. Thurs / Feb 8, 2007, Rayburn Building, Washington DC. For more info, ► click here...
- ► HUG Leaders Conference Call; Tuesday / Feb 20, 2007 / 4:00 PM EST.

To view the complete HAZUS.org News & Events Summary, oclick here...

Please send us your suggestions and updates on news & events of interest to the HAZUS user community, click

http://www.hazus.org/

HAZUS-MH Local Training

HAZUS Multi-Hazards for Floods Course

Register online at https://ks.train.org Search for Course ID: 1020150

Participants can register on KS-TRAIN. If you need assistance or help starting a user account, please call leabel Herrera Schultee at isabel herrera@taa.ks.aov. or 785-274-1412 or contact the KS-TRAIN Help Desk at helpdesk@kohe.state.ks.us or 785-296-5655.

Contact Jessica Frye at Jessica free@frae ks.gov or 785-274-1610 with questions about the course or concerns about lodging reimbursements.



Kansas Emergency Management Training Office Isabel Herrera Schultes

Isabel.hemera@taq.ks.gov

P 785-274-1412-F 785-274-

Topeka, Kansas March 22-25, 2010

This course provides in-depth instructions and hands-on exercises that develop the skills needed to effectively use HAZUS-MH for modeling the impacts on communities from riverine and coastal flooding. The focus of the course is on the processes that are used to define a flood hazard and to generate social and economic loss estimations. However, the course also provides a review of the methodologies used to compile the extensive out-of-the-box inventory that is provided with HAZUS and it provides an introduction to the techniques for updating the inventory, which is largely composed of best available national data sources, with more accurate aggregate and site specific local data.

Target Audience

FEMA, State and local government employees involved with or interested in planning for emergencies associated with flooding, earthquake or hurricane events. This includes, researchers, insurance and utility companies.

Prerequisites

Required: basic familiarity with ArcGIS and an understanding of basic concepts related to emergency management. Recommended: ESRI online GIS Tutorial and Introduction to ArcView 9.x

This course is sponsored by E&E Consultants, AECOM, The Kansas Adjutant General's Department, Heartland HUG, and FEMA Region VII

The deadline to register is two weeks before the course starts (Mar. 5, 2010).

Lodging reimbursements will be available for those traveling 60 miles or more (up to 2 nights).

Contact Information

President of the Heartland Hazus Users Group

Michael Eddings

E&E Consultants

Phone: 620-794-6203

Email: mkeddings@yahoo.com

Heartland HAZUS Users Group and Training

Questions?